

CHAIR ASSEMBLY INSTRUCTION GUIDE

for BEVCO Backless Stool Models

- 3000 Series
- Sit Stands
- Maintenance Repair Stools







PARTS LIST



Seat w/control Mechanism (1)



Five-star Base (1)



Pnuematic Cylinder (1)




Glides/Casters
(5)
*Casters not available for Sit

Stand




Footring (optional) (1)






Insert glides or casters into each leg of the base.




Slide footring (if enclosed) onto cylinder. Ensure the tubular ring faces upward. Tighten handwheel securely.



Slide the cylinder into the center of the base.

4



Place seat with control mechanism onto the end of the pneumatic cylinder. Sit on seat to secure fit onto cylinder.